



FUEL TYPE: NATURAL GAS





We can give you a solar heating performance estimate for your town, city or very close by. This includes most countries in the world. The following chart shows the SIS Solar Air Heater performance and savings for cities in the United States and Canada. If your city is not represented pick a city at the same latitude as yours or send us an email and we will send you back the results.

Email: info@solarinfrasystems.com

Please Put in Subject line: What are my Solar Savings?

Please provide in email:

- Your email address
- Your full home address (house number, street, city, (province, state, region) and country)
- The main fuel type that you use
- What it is costing you annually (Canadian or American dollars please)
 Briefly describe the window or area you plan on putting the solar air heater (unobstructed, southern facing, no overhanging roof)

For most international regions we use a Government of Canada/NRC CanmetENERGY developed program and NASA solar data to show the annual fuel savings for just those months which would require a heater. (www.retscreen.net)

* NOTE: Follow installation instructions for optimum results

Heater Installation

The SIS Solar Air Heater has been developed to easily install in a room and operate like an electric room heater. In an average installation, the solar air heater is equivalent to about a 300 to 500 watt electric space heater, depending on the area you live in. The solar heater fan circulates the room air through the staged solar collectors in the heater that heat the air flow with solar energy. The solar heater fan operates by the sunlight shining on a photovoltaic panel (PV) so, unlike a room electric space heater, there is no household electric power required. The solar air heater hangs or is placed in a south facing window and uses solar radiation to heat the room air, to make up the room heat lost through the walls, ceiling, windows, and doors.

Window / Location

Make sure you have a south facing window that will take a solar air heater approximately 24 inches x 48 inches. The heater will fit between the glass and blind or curtains. There is room for venetian blinds which should be left slightly open to allow air flow through the blind louvers. Do not let the front of the heater touch the glass as it will cause a reduction in heat. If the outside temperature is zero $(0^{\circ}F / -17^{\circ}C)$, the inside glass of a standard double pane window will only be about $44^{\circ}F$ ($7^{\circ}C$). You are also losing appoximately 34 btu/hr per sq.ft. area of the window, through conduction and radiative heat loss.

Remember, if the window is low-E glass and/or argon filled, the solar radiation entering the window is filtered too low to make the solar air heater run effectively.

Shading

Look out the window and see if there is shading that will block the sun. In winter the sun is low in the sky and houses or trees can block the solar energy. If you have high trees on the east and west sides of the house, these will cut off your winter morning and afternoon solar radiation (even trees that lose their leaves.) Roof overhangs and depth of the window may also cut off 2-3 hours of solar radiation in the mornings and afternoons. This can cause a reduction in the effectiveness of the solar air heater.

Solar Air Heater Performance Table

The following table calculates how a solar air heater will perform in a room, with a double pane window, at a room temperature of 70°F (21°C), in a city at a specific latitude. (Important for the winter sun orientation.) If your state/province or location is not listed, pick a site closest on the same latitude as where you live. (NOTE: We are constantly adding locations. If your location is not listed, let us know.) The annual average temperature and heating months are listed for each major city. The annual heating months are used to calculate the fuel used to keep the room at the set temperature. The heating zone map will give you an idea of heating costs throughout the country. The solar air heater also uses the annual heating months, but since the sun does not shine all the time in most cities, it also factors the amount of sunny days during these heating months. Winter (65-70%) Spring and Fall (70-80%) Summer (not calculated if it is not a heating month) (80-90%).

Fuel Table Calculation

The fuel table shows the latest unit price for the city and the total fuel cost to heat the room for the annual heating months. The annual fuel cost is also shown for the solar air heater that uses free solar energy and the cost of the home fuel to make up for the non-sunny days during the heating months. The difference between the normal heating fuel used with no solar and the heating fuel used with a solar air heater is the annual solar savings for the heating months.

A simple payback is calculated by dividing the manufacturer's suggested retail price with the annual cost with solar, to show the number of years it will take to pay for the cost of the solar heater, in fuel savings.

The 15 year fuel savings give you an idea of what a solar air heater can save, where energy is increasing 10% per year, inflation is 2% and a discount of 5%. (Take a look on the Electricity Table at the variation in electricity costs per kwh that is happening all over the country.)

1 4 4 1 4 1	Fuel:	Natura	al Gas	CITOIII		<u> </u>	es III ti				u Can			
SIS Air Heater				MFGS Re	tail Price	\$ 475								
Room Size:						•	l ner 2014 St	⊥ tate/provinc	e Average					
Heater Air Flow:		<u> </u>	<u> </u>		` '			s10% fuel ir			nflation ra	te, 5% disc	ount	
Window:	Std double pane glass				(c) Simpl	y payback:	: number c	of years to r	ecover cos	st of heater	based on	annual fue	l sav	ings
		rgy reduction												
		ne window								mperature	70°F (21°C	C)		
	 				program with NASA solar data (w			Solar Savings with Residential			Natural Gas Heating			
NATURAL	SAS Site Solar D				Double		Annual		Solai Savings with i		Net Net	- nealing		
				Pane		SIS Solar	SIS Solar	Fuel Unit		Annual	Annual	Simple		year
City	Latitude	Ave annual	Ave Heating	Window	Heating Zone	Heater	Heater	Cost	Annual Fuel Cost	Fuel Cost	Fuel	Payback		Fuel wings
Oity	Latitude	temp °F	Months	Solar	(See Map)		Ave Temp.	\$/1000cuft	no Solar \$	with Solar	_	Years		h Solar
				Radiation kwh/ft2/D	(,	Million BTU	Rise °F	\$(a)	,	\$	with Solar \$ (c)	(c)	-	\$(b)
AK Anchorage	N61.2°	37.4	12	0.156	6	3.4	11.8	\$ 9.43	\$ 163	\$ 85	\$ 78	6.09	\$	2,257
CA Los Angeles	N33.9°	62.5	7	0.322	2	2.7	14.9	\$ 11.06	\$ 43	-\$ 15	\$ 58	8.19	\$	1,539
CO Denver	N39.8°	50.3	9	0.299	5	3.5	15.3	\$ 7.84	\$ 93	\$ 25	\$ 68	6.99	\$	1,902
FL Maimi	N25.7	75.1	0	0.306	1	1.8	13.1	\$ 15.77	\$ 12	-\$ 25	\$ 37	12.84	\$	803
GA Atlanta	N33.4°	60.2	7	0.284	2	2.3	12.6	\$ 12.38	\$ 86	\$ 15	\$ 71	6.69	\$	2,003
HI Honululu	N21°	77	0	0.351	1	2.2	13.9	\$ 32.97	\$ 7	-\$ 97	\$ 104	4.57	\$	3,141
ID Boise	N43.6°	51.9	9	0.288	4	2.6	11.5	\$ 8.58	\$ 70	\$ 28	\$ 42	11.31	\$	970
IL Chicago	N42°	50.2	8	0.257	5	2.4	12.3	\$ 8.11	\$ 96	\$ 37	\$ 59	8.05	\$	1,592
KA Witchita	N37.7°	56.8	7	0.296	3	2.3	13	\$ 9.39	\$ 76	\$ 34	\$ 42	11.31	\$	993
MA Boston	N41.7°	50.6	10	0.237	4	2.7	11.1	\$ 16.28	\$ 187	\$ 67	\$ 120	3.96	\$	3,729
MN Minneapolis	N44.9°	46.5	9	0.254	5	2.9	13.2	\$ 9.27	\$ 134	\$ 51	\$ 83	5.72	\$	2,424
MO St. Louis	N38.7°	55.9	7	0.263	3	1.8	10.1	\$ 8.02	\$ 65	\$ 34	\$ 31	15.32	\$	582
MT Butte	N46.0°	40	12	0.249	5	3.7	12.5	\$ 8.31	\$ 150	\$ 56	\$ 94	5.05	\$	2,821
NM Albuquerque	N35°	57.2	7	0.362	4	3	16.6	\$ 8.76	\$ 55	\$ 10	\$ 45	10.56	\$	1,088
NV Los Vegas	N36.1°	68.6	5	0.368	4	4.1	17.6	\$ 9.57	\$ 45	-\$ 19	\$ 64	7.42	\$	1,777
NY New York	N40.8°	54	8	0.257	3	2.3	11.6	\$ 11.47	\$ 111	\$ 39	\$ 72	6.60	\$	2,047
OR Portland	N45.6°	54	10	0.229	3	2.9	11.8	\$ 10.18	\$ 97	\$ 24	\$ 73	6.51	\$	2,081
TX Dallas	N36.0°	55.3	7	0.322	1	2.8	15.2	\$ 8.47	\$ 81	\$ 19	\$ 62	7.66	\$	1,682
VT Burlington	N44.5°	46.3	9	0.243	5	2.7	12.2	\$ 13.04			\$ 112	4.24	\$	3,445
WA Seattle	N47.5°	52.1	10	0.217	4	2.8	11.4	\$ 10.76			\$ 77	6.17	\$	2,229
WI Madison	N43.1°	47.3	9	0.255	5	2.9	13	\$ 9.66	\$ 137	\$ 49	\$ 88	5.40	\$	2,606
AB Edmonton	N53.3°	35.9 (2.16°C)	12	0.232	5	3.5	13.2	\$5.84/GJ	\$ 124		\$ 74	6.42	\$	2,112
BC Vancouver	N49.0°	49.4 (9.66°C)	12	0.202	5	2.6	9.6	\$9.564/GJ				6.01	\$	2,283
ONT Toronto	N43.7°	45 ((7.22°C)	10	0.233	5	2.5	11.2	\$8.84/GJ	\$ 93	\$ 39	\$ 54	8.80	\$	1,432

Table: SIS Solar Air Heater Perfomance for Cities in the United States and Canada

Technology and products covered under patents USA 13,082,680, Sept 22,2014, Canada 2,736,792 Jan 22, 2013 and world patents pending.

Contact us to learn more about our revolutionary infrared technology.

Solar-Infra Systems International Ltd. 209-19138 26th Ave Surrey, British Columbia Canada V3S 3V7

Tel: 604 535 2056

Toll free (Canada & USA): 1-855-535-2056

